☑ **Professional GPS Tracker Detector**

☑ **Expose 2G/3G/4G GPS Trackers**

☑ **GPS Tracker Magnet Finder**

☑ **GPS Jammer Detector**

☑ **Detect 2G/3G/4G/5G (3300~3800MHz)**

Handy and more efficient, the best tool to find covert GPS tracker

This device is **special made of detecting GPS tracker**, no matter what kind of transmission technologies and cell networks (mobile phone system): GPRS (mobile data transmission) or SM (Short message), 2G or 3G or 4G.

Furthermore, this device has an add-on **Magnet Finder** to help user to find magnetic mount GPS tracker, no matter in indoor or outdoor.

● AUTO ENVIRONMENT CHECK

After power-on self-test, this device will run auto environment check. This device will **beep 5 times** to notify the user if switch on this device in strong noise place, so as base station, TV station, construction machine or welding processing where emit or occur high electric waves.

This device will be interfered with those high noises and could not be able to do detection of GPS tracker in such place, please change to another quiet place.

This advanced technology help user get good detecting result in most of places, no matter expert or novice. User never leads to poor or failed detection result.

● RELIABLE DEFAULT BENCHMARK

After environment check, it will stay at default benchmark of **Level 3** and the 7 segment display will show 3. **The default benchmark** is one of our core technology, can fit for different environments all over the world.

● FIND MAGNETIC MOUNT GPS TRACKER

This add-on device can help user to check if there is magnetic mount GPS tracker, no matter the GPS tracker is switched on or off.

GPS tracker can not send out signals in the place with poor GPS signal, such as: downtown street with high-rise buildings, dense woods, metal shelters, near high-voltage tower and indoor parking lots, etc. This magnetic detector can assist in detecting magnetic mount GPS tracker.

● POWER-ON SELF-TEST

Every time this device is switched on, this device will do power-on self-test. The 8 **signal strength indication LEDs** will be put out one-by-one, from 8 7 6 … to 0. The 7-segement LED also shows 8 7 6 … to 0 synchronously.

● SMART INDICATION OF ALL STATUS

No.	NAME	DESCRIPTION
1	Power	Switch on
2	Beep - Vibra	Beep – LED on, Vibration – LED off
3	2G / 4G	2G/4G detection mode
4	3G	3G 2100 detection mode
5	Detecting	In detecting
6	GPS Tracker	Detected signal of GPS tracker, transmitting bug, spy camera, GPS signal jammer
7	Battery low	Battery power running down
8	Charging	Status of battery charging

● TWO KINDS OF WARNING MODE

1. **Beep:** Audible alarm (default)
2. **Vibra:** Vibration

● AUTO INDICATION OF DETECTING STATUS

1. **Detecting**: Yellow LED blinking
2. **GPS Tracker**: When detected radio wave from GPS tracker, the blue LED will light up. The 8-LED of signal strength indicator will also light up and the buzzer goes off at the same time.

● BATTERY & CHARGING STATUS



1. **Battery Low** : Warning of battery power running down.
2. **Charging**: When starts charging, indication lights up in red as quick charging, when charging to about 70%, it will change to slow charging, the indication shift to green.

● EXPERT 3G 2100 DETECTION

3G 2100 is difficult to detect, this device has an individual 3G 2100 detector module which has excellent detecting ability, none can compare with.

● SENSITIVITY (DISTANCE) ADJUSTMENT

1. This device applies digital sensitivity adjustment, the default sensitivity level is **3**. The minus (**–**) button in left side can lower the sensitivity. Press it once can lower one level to level 2 and the 7 segment LED shows 2, the detecting distance will become shorter.
2. The lowest detecting sensitivity is **Level 1**.
3. Press the plus (+) button once, can increase one level of the sensitivity, the highest detecting sensitivity is **Level 6**.

● ADDITIONAL BONUS FEATURE

Detect 3G / 4G / 5G (3300~3800 MHz) & GPS Signal Jammer

1. This device has additional features of detecting 3G / 4G / 5G (3300~3800 MHz) signals of wireless bug (hidden microphone), spy camera and GPS signal jammer.
2. The default sensitivity is level 3 which is special for exposing GPS tracker outdoors. Press the plus (**+**) button in left side once, the sensitivity will increase to level 4, the 7 segment LED will show 4 and the detecting distance will become longer. The highest sensitivity level is 6.

● SUPPORT POWER BANK

This device has Mini USB port for connecting power bank for long time use or charging the battery.

SPECIFICATION * Specification may change without notice.

Detecting object	2G / 3G / 4G GPS tracker, bug (hidden microphone), spy camera, **GPS signal jammer & 5G sub6 (3300 ~ 3800 MHz)**	
Dimension	L 11.6 x W 7 x T 3.3 cm (not include antenna)	
Weight	About 160g (not include battery)	
Power	1. AAA / UM-4 rechargeable battery x 4 2. AAA / UM-4 dry battery x 4 3. 5V DC switching power adaptor 4. 5V DC power bank	
Warning mode	1. LED indication	2. Beep sound
	3. Vibration	4. Earphone silent detection
Detecting Distance	About 3 ~ 5 meters * The detecting distance will be varied depending on the environment and the brand, the cell network of GPS tracker, strength of signal source.	