


HD 1080P DVR Camera Module Kit

User Manual
Version: July , 2020



1

Overview:

The HD 1080P DVR Camera Module Kit is a super flexible kit, it can be DIY a nanny camera or security easily.

First, it has two easiest video modes: Continuously recording / motion detect recording.

Second, it supports cycle recording and work when charging.

Usages: Nanny camera, Home/ Shop/ Office/ Warehouse surveillance camera.....


Warning : " illegal use is not allowed! Or, there will be consequences to bear! "

2

In the box:

1 x DVR Camera module kit	1 x 1500 mA battery	1 x USB cable
1 x Micro SD card reader	1 x User manual	1 x Reset pin

Product structure:



- ① Camera
- ② Continuously / Motion detection recording
- ③ Battery port
- ④ Camera indicator
- ⑤ Pause/Off
- ⑥ Battery indicator
- ⑦ USB port for power
- ⑧ On/Off
- ⑨ Micro SD card slot

3

Getting started of camera part

Step1: Insert micro SD card

TIPS: * Use micro SD card speed >= Class 10 & HC marked;
* Better format card by PC before inserting.

Step2: Two video modes:

- 1). Continuously recording mode: Slide switch ② to up "C", plug in battery and slide ON/OFF switch ⑧ to ON for video recording(Blue light blink quickly 3 times, then 2 slowly blink and off);Short press Pause/Off hole ⑤ to pause (Blue light always on).
- 2). Motion detect recording mode: Slide switch ② to up "M", plug in battery and slide ON/OFF switch ⑧ to ON for video recording(Blue&Red light blink quickly 3 times and off);Short press Pause/Off hole ⑤ to pause(Red light always on).

4

Step3: Power off

Press Pause/Off hole ⑤ 5 seconds, blue light blink quickly 3 times, and camera will be powered off.

5

Resolution	=0	(0=1080P,1=720P;2=480P)
Audio_Record	=1	(0=Off,1=On)
Loop_Record	=1	(0=Off,1=On)
Record_Time	=1	(0=1min,1=3min,2=5min,3=10min)
Motion_Level	=2	(0=highest,1=high,2=middle,3=low,4=lowest)
Motion_Time	=1	(0=1min,1=3min,2=5min,3=10min)
Date_Stamp	=1	(0=Off,1=On)
Time_set	=N2017/01/01 00:00:00	(Y=change N=No change)

8

Specification

Resolution	2.0 Mega CMOS
Video pixel	1920*1080
Frames	Max 30fps
WDR function	Yes
Angle	90 Degree
Compressed format	H.264
Video format	MOV
Memory card	Micro SD card>=Class 10 & HC marked
Support memory	Max 64GB
USB interface	USB1.1/2.0
Battery capacity	1500mA
Operation system	2000/XP/Vista/32
Player	Media player/Kmplayer
Recording	1 minute/ around 111MB

6

- TIPS:** 1. When set up, please observe original format and value modification in the document to avoid invalid setting.
2. Save after set up, then turn on again to finish setting finally.

9

FAQ

- Q:** Blue light keep blinking 10 times and off?
A: 1). No card inserted;
2). Card not compatible (card speed must>=Class 10 & HC market).
- Q:** Can't use 64GB micro sd card directly?
A: Please format the 64GB micro sd card by PC before inserting.
- Q:** Not sure if camera is working or not after plug in power?
A: Press side pause key, if turn stable blue light or red light, then it is working.
- Q:** Video play slow when using card reader?
A: Please copy the videos to local PC storage to play smoothly.
- Q:** How to set time stamp?
A: When inserted micro SD card and turn on, device will form a txt file named setting in card automatically. Then you can do camera setting as below when connect to PC or by card reader.

7



The End!